
CONTENTS

No. Description Page


1、Vehicle explosion diagram 1
2、Engine assembly（Kubota） 2
3、Rear frame assembly 4
4、Drive axle assembly 6
5、Turn the console 7
5.1、Brake assembly 8
6、Shield assembly 9
7、Roof assembly 10
8、Front frame 11
9、Working device assembly 12
10、Fuel route（Kubota） 13

1、Vehicle explosion diagram




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0605010042	Front working device	1	
2	LP0605010041	Front frame	1	
3	LP0601060061	Pull rod link bridge	1	
4	LP0602030014	Steering oil cylinder	1	
5	LP0601010062	Pull rod ball head	1	
6	LP0605010046	Rear frame	1	
7	LP0103020006	Engine	1	
8	LP0601060058	Seat	1	
9	LP0601010114	Operating table	1	
10	LP0601060062	Ceiling	1	

2、Engine Assembly（Kubota）




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0111020042	Shock pad	4	
2	LP0608020030	Engine support	1	
3	LP0608020030	Engine support	1	
4	LP0111020122	Fuel pump	1	
5	LP0608020030	Pressure regulating bracket	1	
6	LP0608020030	Throttle cablee securing plate	1	
7	LP0608020030	Engine support	1	
8	LP0608020030	Engine support	1	
9	LP0601020052	Coolant down pipe	1	
10	LP0601020053	Soft connection of air filter	1	
11	LP0601020063	Air filter	1	
12	LP0111020047	Fuel filtration	1	
13	LP0608020030	Air filter bracketair filter	1	
14	LP0608020030	Air filter tube card	1	
15	LP1011020089	Oil-water separator	1	




REF NO.	Part NO .	Name	Q/TY	REMARKS
16	LP0601060072	Radiator	1	
17	LP0601020051	Coolant up pipe	1	
18	LP0103020006	Engine	1	
19	LP0601060065	Silencer soft connection	1	
20	LP0601020048	Muffler asbestor pad	1	
21	LP0601060059	Suppressor	1	
22	LP0601030011	Coupling of shaft	1	
23	LP0102010047	Flywheel housing	1	
24	LP0602010017	Plunger pump	1	
25	LP0602010018	Gear pump	1	

3、Rear frame




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0602030014	Steering oil cylinder	1	
2	LP0608020030	Brake pedal support	1	
3	LP0602010019	Single brake pump	1	
4	LP0111080228	Return filter asbestos pad	1	
5	LP0115030047	Return filter	1	
6	LP0111050003	Oil filter element	1	
7	LP0111050003	Oil filter element	1	
8	LP0602060005	Fuel tank cover	1	
9	LP011109060	Hydraulic oil window	1	
10	LP0608020030	Counterweight plate	1	
11	LP0605010016	U shaped hook	2	
12	LP0601010084	Trailer ball head hook	1	
13	LP0116010048	Battery buckle	1	
14	LP0106010003	Battery	1	
15	LP0604020003	Oil level sensor	1	




REF NO.	Part NO .	Name	Q/TY	REMARKS
16	LP0605010062	Rear frame	1	
17	LP0602050020	Bus-bae	1	
18	LP0602050018	Pressure measuring valve	1	
19	LP0608020030	Solenoid switching valve	1	
20	LP0115030060	Solenoid switching valve	1	
21	LP0601010062	Pull rod ball head	3	
22	LP0601060061	Pull rod link bridge	1	
23	LP0603020065	Steering cylinder with rear frane pin shaft	1	

4、Drive axle assembly




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0601040043	Right-hand typle	1	
2	LP0601040040	Loader drive axle	1	
3	LP0602070009	Loader walking motor	1	
4	LP0601040042	Left-hand tyre	1	

5、Turn the console




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0608020030	Pedal guard front guard	1	
2	LP0602040009	Priority valve	1	
3	LP0601020062	Shock pad	4	
4	LP0601020070	Pedal guard	1	
5	LP0601010076	Dust jacket	1	
6	LP0608020030	Pedal access plate	1	
7	LP0601010114	Steering console	1	
8	LP0601010066	Accelerator	1	

5.1、Brake Assembly




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0601020060	Pedal non-slip pad	1	
2	LP0603020054	Left foot pedal	1	
3	LP0608020030	Brake bridge frame	1	
4	LP0608020030	Angle sensor bracket	1	
5	LP0608020030	Brake pedal support	1	
6	LP0604020042	Brake light switch	1	
7	LP0602010019	Single brake pump	1	
8	LP0601010064	Brake pump push rod	1	
9	LP0608020030	Brake connecting rod	1	
10	LP0604020038	Angle sensor	1	

6、Shield assembly




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0608020030	Single pump oil can stand	1	
2	LP0601010078	Single pump oil can	1	
3	LP0601060074	Shield	1	
4	LP0604020039	Tail lamp	2	
5	LP0601010067	Handbrake	2	
6	LP0111080036	Seat hinge	1	
7	LP0601010068	Air support	2	
8	LP0608020030	Seat cover	1	
9	LP0601060077	Seat	1	
10	LP0106040054	Mains switch	1	
11	LP0106020356	Rear guard lock	1	

7、Roof Assembly




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0601060062	Ceiling	1	
2	LP0601010070	Gas strut	2	
3	LP0607030001	Ceiling handrail	2	
4	LP0601010072	Extinguisher	1	
5	LP0604020040	Ceiling warning light	1	
6	LP0111080467	File box	1	
7	LP0108010101	Ceiling headinghts	1	
8	LP0601010069	Rearview mirror	2	

8、Front frame




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0601040043	Right-hand typle	1	
2	LP0601040040	Loader drive axle	1	
3	LP0601040042	Left-hand tyre	1	
4	LP0601010075	Loader fender	1	
5	LP0608020030	Stop rod	1	
6	LP0602070009	Loader walking motor	1	
7	LP0603020065	Front frame with steering cylinder pin	1	
8	LP0608020030	Left lamp holder	1	
9	LP0608020030	Right lamp holder	1	
10	LP0608020030	Left side headlight	1	
11	LP0608020030	Right side headlight	1	
12	LP0608020030	Cylinder support plate	1	
13	LP0605010041	Front frame	1	
14	LP0603020064	Front frame with bucket cylinder	1	
15	LP0603020063	Front frame couping arm cylinder	1	
16	LP0608020030	Front frame access plate-1	1	
17	LP0608020030	Front frame access plate-2	1	
18	LP0608020030	Tubing guard plate	2	

9、 Working device assembly



REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0603020057	Boom fixed pin	1	
2	LP0603020056	Boom pin Oplate	2	
3	LP0602050019	Left boom iron tube	1	
4	LP0602050019	Right boom iron tube	1	
5	LP0608020030	Three-way ball valve mounting	2	
6	LP0602040001	Three-way ball valve	2	
7	LP0602030017	Boom cylinder	2	
8	LP0603020059	Boom with cylinder pin	2	
9	LP0603020055	Pin baffle	4	
10	LP0605010042	Swing arm	1	
11	LP0602030015	Bucket cylinder	1	
12	LP0605010043	Rocker arm	1	
13	LP0603020061	Rocker with connecting rod pin	1	
14	LP0603020060	Boom with quick-change pin	3	
15	LP0603020058	Boom with rocker arm pin	1	
16	LP0605010044	Connecting rod (bent)	1	
17	LP0603020062	Quick-change pin	1	
18	LP0602030022	Double head telescopic cylinder	1	
19	LP0605010045	Bucket mounting rack	1	
20	LP0601060073	Bucket	1	

10、Fuel route（Kubota）



REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP1011020089	Oil-water separator	1	
2	LP0111020047	Colation	1	
3	LP0111020081	Oil pump	1	
4	LP0111020047	Fine filtration	1	
5	LP0103020006	Engine	1	
6	LP0601010063	Tower reducer	1	
7	LP0111020010	Oil return check valve	1	
8	LP0115040018	Diesel tank	1	